


## How to insert a Micro SD card into FI9803EP

**Step 1:** Unscrew the top cover.




Picture 1

**Step 2:** Unscrew the front cover to open the camera and access the Micro SD Card slot.



Picture 2

**Step 3:** Insert a Micro SD Card in the location shown below.



Picture 3

**Step 4:** Assemble the camera.

Please see picture 4, the three holes below should at the same line, and the two holes at the bottom are for the bracket, not the top cover.



Picture 4

**Attention:**

Remember to screw the camera back together tightly to make a secure seal, and prevent any moisture entering the camera when installed outside.

**End**

by Technical Support Team