

How to access the Foscam FI9853EP MicroSD Card Slot.



Remove the top housing and base from the Foscam FI9853EP dome camera as shown below.



Unscrew the top and bottom of the dome to open the camera and access the Micro SD Card slot.



Insert Micro SD Card in the location shown below.

