

How to insert a Micro SD Card into FI9900P

Step1: Take off the 2 screws and remove the front glass cover, please be careful in case to scratch the glass;



Step2: Take off the 4 screws in picture below;



Step3: Carefully take out the whole lens board, please find the SD card slot on the inside PCB;



Step4: Insert your micro SD card, then assemble back your FI9900P.

End

by Foscam Technical Support Team