Upgrade Guidance for FI9821P

Note:
This firmware is for camera FI9821P.
Updating with the wrong firmware could severely damage and/or break your camera. Please make sure the firmware is correct.
Upgrading procedure:s

Preparation before upgrading.

1. Connect camera to router with an Ethernet cable to upgrade firmware;
2. DO NOT upgrade firmware via wireless;
3. Keep power on during the upgrading;
4. Unplug the SD card, and reboot your camera first.

Logging your camera as administrator first, upgrade firmware on web page.

Step 1: Click **Settings** → **System** → **System Upgrade.**
Click **Browse** → choose **App Firmware** → click **Open** → Click **System Upgrade**.

Step 2: "**Upgrading, do not power off … Xs**" pop up, camera IP will disappear from the IP Camera Tool. Then camera will reboot itself, please wait till the camera IP reappear in the IP Camera Tool.

Step 4: Login again to check the **System Firmware Version, Application Firmware Version** and **Plug-In Version**.

Congratulations, your camera successfully upgraded to the latest firmware!

Note:

1. Remove the old plug-in if it has not upgraded, camera will prompt you to re-load the new one when login next time.
2. Please restore to factory settings after upgrade successfully, in order to change some default factory settings.
3. The correct firmware version after upgrade:

System Firmware Version	1.4.1.5
Application Firmware Version	1.11.1.19
Plug-In Version	2.0.1.4